

Rod Pocket / Tab Top Valance Installation Instructions

Getting Started

Carefully read all instructions before you begin installation. Please make sure that you have your rod drapery hardware mounted to the wall.



Installation Instructions

1. Insert your valance hardware through the rod pocket/tabs at the top of the valance.
2. Once the valance is in place, install the rod onto the wall mounted hardware
3. Space out the folds to achieve the desired look



Valance Care

Once the valance is installed, most wrinkles and folds will hang out on their own within 1 - 2 weeks. A garment / commercial steamer may also be used to help smooth out the wrinkles.

Certain fabrics like silks or linens have natural characteristics that steaming won't remove.



Questions?

Our dedicated customer service team is available to answer any questions about your valance. Contact us at 1-800-256-5005 or email customercare@regaldrapes.com.