

REGAL DRAPES


Motorized Roman Shades Instructions

Charging Instructions

The battery pack included in the roman shade provides approximately 6 month's of use when fully charged (This estimate will vary based on shade size, fabric weight & frequency of use. A detached charging cord is included. Plug in and attach the cord to the roman shade to charge the shade battery (approximately 4 hours to full charge). Charge the roman shade prior to first use.

Single Channel Remote

The Single Channel Remote is pre-programmed to operate your roman shade.



Pressing the Up button will raise the shade to the uppermost position.

Pressing the Stop button at any point during operation will stop the shade in place.

Pressing the Down button will lower the shade to the bottom most position.

The blank button is a programming button that is not used in daily operation.

Warranty

The motor and battery pack are covered by a 5 year limited warranty as long as the product is installed according to instructions. Regal Drapes reserves the right to repair or replace the unit at their discretion. For more information please visit our website at www.regaldrapes.com.

Questions

For any questions or support please call our customer service at 1-800-256-5005 or email customercare@regaldrapes.com.